

Manual, Assembly instruction: Brodit 853145

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Pull the dashboard upwards to widen the gap on top of the dashboard. Hook the long upper part of the ProClip into the gap on top of the dashboard.

2. Pull the lower part of the ProClip towards you/downwards. Hook the lower part of the ProClip under the edge of the dashboard.

3. Press upwards on the lower part of the ProClip so it hooks under the edge of the dashboard.

4. The ProClip is in place.