

Manual, Assembly instruction: Brodit 853155

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Hook the lower part of the ProClip under the frame surrounding the air vent.
2. Press forwards on the ProClip so the upper part snaps into the gap between the frame surrounding the air vent and the dashboard.
3. The ProClip is in place.
4. The ProClip is in place.