

## Manual, Assembly instruction: Brodit 853161

Center mount

1.)



2.)



3.)



4.)



**Attention! Read all instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the stereo and the frame surrounding the air vent to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the angled edge on the right part of the ProClip into the gap above the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap between the dashboard and the frame surrounding the instrument panel. Press the grooved edge on the left part of the ProClip into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.