

Manual, Assembly instruction: Brodit 853162

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed gap openers into the gap between the frame surrounding the air vent and the control panel to widen the gap. Place the gap openers approx. 10 cm apart. Peel off the adhesive tape covers on the ProClip.
2. Press the short left part of the ProClip into the gap between the gap openers. Pull out the gap openers.
3. Press a gap opener into the gap between the dashboard and the panel surrounding the air vent. Hook the long right part of the ProClip into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.