

Manual, Assembly instruction: Brodit 853171

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the air vent to widen the gap.
2. Place the lower part of the ProClip into the gap next to the gap opener, so far to the left as possible. Press forwards on the lower part of the ProClip so it goes into the gap. Pull out the gap opener.
3. Press the gap opener into the gap between the dashboard and the frame surrounding the air vent. Press forwards on the upper part of the ProClip so it goes into the gap next to the gap opener. Pull out the gap opener. Pull the ProClip slightly left/rightwards so you feel it is properly in place.
4. The ProClip is in place.