

Manual, Assembly instruction: Brodit 853173

Angled mount, High

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the air vent to widen the gap. Press the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
2. Press the gap opener into the gap between the dashboard and the frame surrounding the air vent. Press the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Adjust the ProClip sideways to the correct position.
4. The ProClip is in place.