

Manual, Assembly instruction: Brodit 853174

Center mount ONLY for models with brown wood grain panel.

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the dashboard to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the left part of the ProClip into the gap above the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the control panel and the surrounding frame. Press the right part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.