

Manual, Assembly instruction: Brodit 853175

Angled mount ONLY for models with brown wood grain panel.

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed Gap Opener (Spaltöffner)s into the gap between the dashboard and the frame surrounding the control panel to widen the gap. Place the Gap Opener (Spaltöffner)s approx. 10 cm apart. Peel off the cover of the adhesive tape on the ProClip.
2. Press the right part of the ProClip, with adhesive tape, into the gap between the Gap Opener (Spaltöffner)s. Pull out the Gap Opener (Spaltöffner)s.
3. Press the Gap Opener (Spaltöffner)s into the gap between the control panel and the surrounding the frame, place one above and one below the ProClip. Press the left part of the ProClip into the gap between the Gap Opener (Spaltöffner)s. Pull out the Gap Opener (Spaltöffner)s.
4. The ProClip is in place.