

Manual, Assembly instruction: Brodit 853178

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Peel off the adhesive tape cover on the ProClip. Place the ProClip in your hand so the face plate is downwards. Place the ProClip inside the glove compartment so the long right part is in the center behind the gap between the glove compartment and the dashboard. Press the curved edge on the right part into the gap by pressing it upwards/towards you. Hold the right part in the gap in the same time as you flip the left part towards you. Continue pressing upwards so the curved edge hooks into the gap.

2. Slide the ProClip leftwards in the gap.

3. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard to widen the gap. Pull the ProClip leftwards so it hooks into the gap below the gap opener. Press forwards on the ProClip so the grooved edge on the left part snaps into the gap. Pull out the gap opener.

4. The ProClip is in place.