

Manual, Assembly instruction: Brodit 853180

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard to widen the gap. Peel off the cover of the adhesive tape on Part 1. Press Part 1 into the gap below the gap opener.

2. Press Part 1 rightwards, away from the steering wheel, so the angled edge hooks behind the control panel and the adhesive attaches to the dashboard. Pull out the gap opener.

3. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match. Screw Part 2 onto Part 1 with the enclosed screws. **NOTE!** Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.