

Manual, Assembly instruction: Brodit 853181

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the upper part of the ProClip, with adhesive tape, into the gap between the panels above the air vent.
2. Pull the ProClip downwards,/towards you. Hook the angled edge on the lower part of the ProClip into the lower part of the air vent housing.
3. Press downwards on the ProClip so the lower part hooks under the edge.
4. The ProClip is in place.