

Manual, Assembly instruction: Brodit 853189

Center mount



Please read all instructions and look at the pictures before attaching the ProClip. This ProClip can be attached to the left or to the right of the air vent. You can also use one mount on each side of the air vent.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the dashboard edge, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press/hook the angled edge on the lower part of the ProClip over the lower edge of the trim.

3. Press forward on the upper part of the gap opener to widen the gap more. Hold it in that position, then press firmly forward on the lower part of the ProClip so the upper part of the ProClip is flexing upwards. The angled edge will go into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.