

Manual, Assembly instruction: Brodit 853192

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the hatch to the coin compartment. Press the thin end of the enclosed gap opener into the gap in the control panel, below the hazard-button, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the grooved edge on the lower part of the ProClip into the gap to the left of the gap opener.
2. Slide the ProClip leftwards, towards the steering wheel. Pull out the gap opener.
3. Hook the upper part of the ProClip, with adhesive tape, over the edge of the coin compartment.
4. The ProClip is in place.