

Manual, Assembly instruction: Brodit 853196

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the grooved edge into the gap between the air vent frame and the dashboard overhang. Press until you see or hear + feel it snaps into place.
2. Press firmly forward on the lower part of the ProClip so the adhesive tape attaches to the wood grain panel.
3. Press firmly forward on the "inside" part of the ProClip optimal attachment of the adhesive tape further.
4. The ProClip is in place.