

Manual, Assembly instruction: Brodit 853197

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Press the thin end of the enclosed gap opener into the gap between the wood grain panel and the padded dashboard, to widen the gap.

2. Peel off the cover of the adhesive tape on Part 1. Place the angled edge of Part 1 towards the gap below the gap opener. Press the angled edge firmly into the gap and at the same time: bend Part 1 to the right until you hear/feel it snaps into place and the adhesive tape attaches to the console edge. Pull out the gap opener.

3. Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the left side attaching to the center console panel frame. Screw Part 2 onto Part 1 using the enclosed screws. NOTE! Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.