

Manual, Assembly instruction: Brodit 853202

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Remove the screw in the dashboard under the air vent. Peel off the cover of the adhesive tape on the ProClip.
2. Press the ProClip into the gap between the upper and the lower part of the dashboard.
3. Place the ProClip so the holes match. Screw the ProClip into place with the enclosed screw.
4. The ProClip is in place.