

Manual, Assembly instruction: Brodit 853204

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the control panel frame to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Place the ProClip under the gap between the air vent frame and the air vent housing. Press the angled upper edge upwards into the gap, start by pressing one corner into the gap and then press the ProClip all the way into the gap.
3. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.