

Manual, Assembly instruction: Brodit 853210

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Open the glove compartment. Press the angled edge on the right side of the ProClip into the gap between the center console side wall and the glove compartment frame.

2. Flip the ProClip towards the center console so the angled edge on the right side of the ProClip hooks behind the glove compartment frame.

3. Hook the angled edge on the left side of the ProClip over the console edge and press it into the gap between the center console panel and the console edge.

4. The ProClip is in place.