

Manual, Assembly instruction: Brodit 853211

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the lower part of the ProClip into the gap between the control panel and the panel.

3. Press forwards on the ProClip, then press upwards so the curved lower part hooks into the gap.

3. Hook the upper part of the ProClip, with adhesive tape, over the lower edge of the air vent housing. Press downwards on the upper edge of the ProClip so the adhesive tape attaches.

4. The ProClip is in place.