

Manual, Assembly instruction: Brodit 853217

Angled mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press/hook the angled edge on the left side of the ProClip into the gap between the climate control panel and the surrounding panel frame.
2. Press firmly forward on the right side of the ProClip so the angled edge goes into the gap in the center console sidewall. Press until you see or hear/feel it snaps into place.
3. The ProClip is in place.
4. The ProClip is in place.