

Manual, Assembly instruction: Brodit 853218

Center mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the ProClip over the center console edge.
2. Press firmly forward on the right side of the ProClip so the grooved edge goes into the gap between the padded console edge and the panel surrounding the stereo frame. Press until you see or hear/feel it snaps into place.
3. Press firmly forward on the left side of the ProClip so the grooved edge goes into the gap between the padded console edge and the instrument panel frame. Press until you see or hear/feel it snaps into place.
4. The ProClip is in place.