

Manual, Assembly instruction: Brodit 853221

Angled mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment door. Peel off the cover of adhesive tape on the ProClip. Place the curved edge on the left side of the ProClip towards the gap between the climate control panel and the center console edge.
2. Press the curved part into the gap and flip the ProClip to the right, towards the glove compartment.
3. Press the thin end of the enclosed gap opener into the gap in the center console sidewall, to widen it. At the same time: press firmly forward on the right side of the ProClip so the angled edge goes into the gap above the gap opener. Press until you see or hear/feel it snaps into place. Close the glove compartment door.
4. The ProClip is in place.