

Manual, Assembly instruction: Brodit 853223

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the Gap Opener (Spaltöffner) into the gap between the stereo and the surrounding panel frame, to widen the gap.
2. Peel off the cover of adhesive tape on the ProClip. Press the grooved edge on the lower part of the ProClip into the gap next to the Gap Opener (Spaltöffner). Press until you see or hear + feel it snaps into place. Pull out the Gap Opener (Spaltöffner).
3. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the dashboard and the "coin box", to widen it, and at the same time: press forward on the upper part of the ProClip so the angled edge snaps into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner) and press down on top of the ProClip for best possible attachment.
4. The ProClip is in place.