

Manual, Assembly instruction: Brodit 853224

Angled mount ONLY for automatic gear shift.



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment door. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the left side of the ProClip into the gap between the climate control panel and the surrounding panel frame.

2. Press firmly forward on the right side of the ProClip so the angled edge goes into the gap between the center console edge and the glove compartment frame. Press until you see or hear/feel it snaps into place.

3. Press the side of the ProClip towards the center console wall to make sure the angled edge is all the way into the gap. Close the glove compartment door.

4. The ProClip is in place. NOTE: For automatic transmissions only. When using this ProClip in a manual shift car, the shifter might hit your device in 5th gear.