

Manual, Assembly instruction: Brodit 853231

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the climate control panel and the surrounding panel frame, to widen the gap.

2. Peel off the cover of the adhesive tape on the ProClip. Press the angled edge on the lower part of the ProClip into the gap next the gap opener. Pull out the gap opener.

3. Slide the ProClip all the way to the left. Press the thin end of the enclosed gap opener into the gap between the console edge and the dashboard, to widen the gap. At the same time: Press firmly forward on the upper part of the ProClip so the angled edge hooks over the console edge next to the gap opener. Press until you see or hear/feel it snaps into place.

4. The ProClip is in place.