

Manual, Assembly instruction: Brodit 853241

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the thin end of the upper part of the ProClip into the air vent.

2. Place your fingers underneath the lower part of the ProClip and press upwards so the thin end of the lower part goes into the air vent and attaches to the ledge.

3. The ProClip is in place.

4. The ProClip is in place.