

Manual, Assembly instruction: Brodit 853245

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the left side of the ProClip over the center console edge.
2. Hold the ProClip with both hands and hook the angled edge on the right side of the ProClip over the console edge but DONT attach the tape yet. Slide the ProClip upwards so the left side of the ProClip goes into the gap between the console edge and the dashboard panel.
3. Press forward on the ProClip so it attaches to the console edge.
4. The ProClip is in place.