

Manual, Assembly instruction: Brodit 853246

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent and the wood grain panel, to widen the gap.

2. Peel off the cover of the adhesive tape on the ProClip. Press the thin end, with the adhesive tape, on the lower part of the ProClip into the gap next to the gap opener. Press it all the way in. Pull out the gap opener.

3. Place the thin end, with the adhesive tape, onto the air vent ledge. Press down on top of the ProClip for best possible attachment of the adhesive tape.

4. The ProClip is in place.