

Manual, Assembly instruction: Brodit 853247

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the thin angled edge on the left side of the ProClip into the gap between the center console panel and the padded console edge.

2. Place your index fingers on the inside of the ProClip and push it a few millimeters away from the sidewall, and at the same time: press forward with your thumbs so the angled edge on the right side of the ProClip snaps over the padded edge in the sidewall.

3. The ProClip is in place.

4. The ProClip is in place.