

Manual, Assembly instruction: Brodit 853250

Center mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel and the console sidewall, to widen the gap.

2. Peel off the cover of the adhesive tape on the ProClip. Press the angled edge on the right side of the ProClip into the gap between the stereo and the console panel.

3. Press forward with your thumb so the angled edge on the left side of the ProClip snaps into the gap above the gap opener. Place your fingers on the side of the ProClip and push towards the console sidewall to make sure the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.