

Manual, Assembly instruction: Brodit 853251

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the thin end of the enclosed gap openers into the gap between the center dash panel and the padded dashboard, to widen the gap.

2. Press the grooved edge on the upper part of the ProClip into the gap between the gap openers. Press firmly until you see or hear/feel it snaps into place. Pull out the gap openers.

3. Press the gap openers into the gap, on each side of the ProClip, between the center dash panel and the padded dashboard ledge. Press forward on the lower part of the ProClip so the grooved edge goes into the gap between the gap openers. Press firmly until you see or hear/feel it snaps into place. Pull out the gap openers.

4. The ProClip is in place.