

Manual, Assembly instruction: Brodit 853252

Angled mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the padded dashboard edge, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the upper part of the ProClip into the gap between the padded dashboard ledge and the panel frame, and at the same time: flip the lower part of the ProClip down, towards the gap opener, so the angled edge on the upper part of the ProClip hooks behind the panel frame.

3. Press forward on the lower part of the ProClip so the grooved edge goes into the gap above the gap opener. Press firmly until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.