

Manual, Assembly instruction: Brodit 853259

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Peel off the adhesive tape covers on the ProClip. Place the ProClip over the dashboard ledge.
2. Hook the upper part of the ProClip into the coin shelf.
3. Hook the angled edge on the lower part of the ProClip under the dashboard ledge.
4. The ProClip is in place.