

Manual, Assembly instruction: Brodit 853261

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off both adhesive tape covers on the ProClip. Place the angled edge on the lower part of the ProClip in the gap between the ledge and the control panel.
2. Press the lower part of the ProClip into the gap.
3. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the dashboard to widen the gap. Hook the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.