

Manual, Assembly instruction: Brodit 853262

Angled mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off both adhesive tape covers on the ProClip. Hook the long right part of the ProClip into the gap between the frame surrounding the control panel and the dashboard.
2. Hook the left part of the ProClip into the gap between the control panel and the surrounding frame.
3. The ProClip is in place.
4. The ProClip is in place.