

Manual, Assembly instruction: Brodit 853264

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Hook the long lower part of the ProClip under the edge of the dashboard.
2. Pull the upper part of the ProClip towards you/upwards.
3. Hook/Press the angled edge on the upper part of the ProClip into the gap between the climat control panel and the surrounding frame.
4. The ProClip is in place.