

Manual, Assembly instruction: Brodit 853266

Angled mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching piece (the smallest part) Part 2. ProClip face plate

1. Press the thin ends of the enclosed gap opener into the gap between the control panel and the dashboard to widen the gap. Place the gap openers about 10 cm apart. Peel off the cover of the adhesive tape on Part 1. Press the angled edge on Part 1 into the gap between the gap openers.

2. Press to the right on Part 1, away from the steering wheel, so the angled edge hooks behind the control panel and the adhesive attaches to the dashboard. Pull out the gap openers. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match.

3. Screw Part 2 onto Part 1 with the enclosed screws. NOTE! Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.