

Manual, Assembly instruction: Brodit 853267

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of one of the enclosed gap openers into the gap between the control panel and the dashboard to widen the gap. Press the other gap opener into the gap between the control panel and the air vent frame. Press the lower part of the ProClip into the gap above the gap opener between the control panel and the dashboard.

2. Press the right part of the ProClip into the gap next to the gap opener between the control panel and the air vent frame. Pull out the gap openers.

3. Press a gap opener into the gap between the air vent frame and the dashboard, above the ProClip. Press the upper part of the ProClip into the gap below the gap opener. Pull out the gap opener.

4. The ProClip is in place.