

Manual, Assembly instruction: Brodit 853269

Center mount, Low

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard to widen the gap. Align the gap opener with the gap in the control panel. Peel off the cover of the adhesive tape on the ProClip.
2. Press the lower part of the ProClip into the gap above the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap to the right of the ProClip, between the control panel and the dashboard. Press the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.