

Manual, Assembly instruction: Brodit 853277

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel frame and the dashboard to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Hook the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Hook the upper part of the ProClip over the lower edge of the air vent.
4. The ProClip is in place.