

Manual, Assembly instruction: Brodit 853281

Center mount NOT for M-Sport.

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between frame surrounding the air vent and the control panel, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the lower part of the ProClip, with adhesive tape, into the gap next to the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap between the frame surrounding the air vent and the frame surrounding the display. Press forwards on the upper part of the ProClip so the angled edge hooks behind the frame surrounding the air vent, under the gap opener. Pull out the gap opener.
4. ProClip is in place.