

## Manual, Assembly instruction: Brodit 853282

Angled mount NOT for M-Sport.

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Peel off the cover of the adhesive tape on the ProClip. Press the thin end of the gap opener into the gap between the padded ledge and the air vent panel frame, to widen the gap.
2. At the same time: press forward on the upper part of the ProClip so the angled edge slides underneath the gap opener and into the gap. Pull out the gap opener.
3. Press the gap opener into the gap between the climate control panel and the air vent panel frame. Press the thin end with adhesive tape on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.