

Manual, Assembly instruction: Brodit 853289

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the stereo, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the grooved edge on the right part of the ProClip into the gap below the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap between the frame surrounding the control panel and the frame surrounding the instrument panel. Hook/Press the angled edge on the left part of the ProClip into the gap below the gap opener. Pull out the gap opener.
4. The ProClip is in place.