

Manual, Assembly instruction: Brodit 853290

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the stereo, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the grooved edge on the left part of the ProClip into the gap below the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the air vent frame and the dashboard. Hook the right part of the ProClip, with adhesive tape, into the gap below the gap opener. Pull out the gap opener.

3. The ProClip is in place.

4. The ProClip is in place.