

Manual, Assembly instruction: Brodit 853293

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Loosen the two screws in the frame surrounding the control panel, on each side of the air vents.
2. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the stereo, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press forwards on the upper part of the ProClip so the angled edge hooks into the gap between the frame surrounding the control panel and the dashboard. Press the gap opener into the gap next to the ProClip and prize carefully so the gap is widened. Press downwards on top of the ProClip so it goes all the way into the gap. Pull out the gap opener. Retighten the screws.
4. The ProClip is in place.