

Manual, Assembly instruction: Brodit 853298

Center mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the thin end of the enclosed gap opener into the gap between the stereo and the air vent frame, to widen the gap. At the same time: Hold the ProClip in an almost 45 degree angle towards the dashboard and press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Then flip it upwards, towards the air vent, so the angled edge hooks behind the stereo panel.

2. Slide the ProClip towards the steering wheel, to desired position. Pull out the gap opener.

3. Press the gap opener into the gap between the air vent panel and the coin box panel. Press firmly forward on the upper part of the ProClip so the angled edge hooks into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.