

Manual, Assembly instruction: Brodit 853299

Center mount Mercedes Benz - ONLY for automatic gear shift.



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the gap opener into the gap between the stereo frame and the air vent frame, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Place the angled edge on the upper part of the ProClip into the air vent. Flip the ProClip down, towards the gap opener, so the angled edge on the upper part of the ProClip hooks over the air vent bar.
3. Press firmly forward on the lower part of the ProClip so the grooved edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.