

Manual, Assembly instruction: Brodit 853301

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Place the thin edge with adhesive tape on the lower part of the ProClip into the air vent. (Note: the air vent can still be adjusted)
2. Place your fingers on top of the ProClip and press down towards the air vent.
3. While pressing down, push the upper part of the ProClip forward so the angled edge hooks into the gap between the information screen and the surrounding panel frame. Press down on the inside of the ProClip with your index finger for best possible attachment of the adhesive tape.
4. The ProClip is in place.