

Manual, Assembly instruction: Brodit 853302

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the angled edge on the left side of the ProClip into the gap between the center console panel frame and the console edge.
2. Press firmly forward on the right side of the ProClip so the angled edge hooks over the console edge by the carpet.
3. Press firmly forward, towards the sidewall, to make sure the angled edge is properly hooked over the console edge.
4. The ProClip is in place.