

Manual, Assembly instruction: Brodit 853303

Center mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console frame and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Hook the angled/curved edge on the right side of the ProClip into the gap between the air vent and the surrounding panel frame. (Note: you can still adjust your vent)
3. Press firmly forward on the left side of the ProClip so the angled edge on the left side snaps into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.